



POOL PEBBLE REPAIR KIT

A Do It Yourself Pool Patch Repair Kit

POOL PATCH INSTRUCTIONS

1. Lower water below repair area.
2. Remove loose cement and chip area down a minimum of a ¼ inch deep.
3. Add 2 oz. of LIQUID CEMENT BONDER per 1½ lb. of DRY POOL PATCH CEMENT MIX. Add water and mix until a putty consistency is achieved.
4. Trowel POOL PATCH firmly filling the area. Trowel till POOL PATCH is smooth and flat. Remove excess from edges with a moist sponge. After POOL PATCH starts to cure, spray with water using a spray bottle to expose the pebble. If POOL PATCH has a film after cure time, it can be removed by wetting the surface area with water and pouring a mixture of 1 part muriatic acid to 3 parts water on the patched area. Allow mixture to expose area 1 minute and rinse off using a water hose.

ALLOW TO CURE 12 HOURS BEFORE FILLING POOL

WARNING:

Contains Cement, an Alkaline substance irritating to eyes and skin. Contains Acrylic Resin Cement Bonder. Should product contact eyes, flush them immediately and repeatedly with water and call a Physician. **DO NOT TAKE INTERNALLY.** In case of skin contact, rinse immediately with water. **USE OF RUBBER GLOVES AND EYE PROTECTION IS RECOMMENDED.**

KEEP OUT OF REACH OF CHILDREN

Pool Patch, Phoenix, Arizona
poolpatch.com